




Creator:	Ian	Project:	Tank Controller	Customer:	
Checked:		Installation:		Diagram No.:	1
Date:	1/5/16 10:23 AM/10/4/16 8:42 AM	File:	Tank Controller v3.5.lsc	Page:	1 / 12




Creator:	Ian	Project:	Tank Controller	Customer:	
Checked:		Installation:		Diagram No.:	1
Date:	1/5/16 10:23 AM/10/4/16 8:42 AM	File:	Tank Controller v3.5.lsc	Page:	3 / 12





Creator:	Ian	Project:	Tank Controller	Customer:	
Checked:		Installation:		Diagram No.:	1
Date:	1/5/16 10:23 AM/10/4/16 8:42 AM	File:	Tank Controller V3.5.lsc	Page:	5 / 12


Filter Control



Creator:	Ian	Project:	Tank Controller	Customer:	
Checked:		Installation:		Diagram No.:	1
Date:	1/5/16 10:23 AM/10/4/16 8:42 AM	File:	Tank Controller V3.5.lsc	Page:	6 / 12

SD Card Logging

Use edge AND and NAND to detect change in signal level and log to SD card.




Creator:	Ian	Project:	Tank Controller	Customer:	
Checked:		Installation:		Diagram No.:	1
Date:	1/5/16 10:23 AM/10/4/16 8:42 AM	File:	Tank Controller V3.5.lsc	Page:	7 / 12

PulseWin

Creator:	Ian	Project:	Tank Controller	Customer:	
Checked:		Installation:		Diagram No.:	1
Date:	1/5/16 10:23 AM/10/4/16 8:42 AM	File:	Tank Controller V3.5.lsc	Page:	8 / 12

Menu Display Control Using Up & Down Keys



Creator:	lan	Project:	Tank Controller	Customer:	
Checked:		Installation:		Diagram No.:	1
Date:	15/16 10:23 AM/10/4/16 8:42 AM	File:	Tank Controller V3.5.lsc	Page:	9 / 12



Creator:	lan	Project:	Tank Controller	Customer:	
Checked:		Installation:		Diagram No.:	1
Date:	1/5/16 10:23 AM/10/4/16 8:42 AM	File:	Tank Controller V3.5.lsc	Page:	10 / 12

